

# FIREARM CLEANING AND BARREL BREAK IN PROCESS

Thanks to Team Member D.D., Victoria, BC, Canada (Rev. 09/2010)

## BREAK IN PROCESS

Run Patchworm with 1 patch soaked with Prolix, both sides. Sit 10 min to loosen foreign material. Repeat if necessary.

Run a super intensive felt cleaning button dipped in Prolix and smeared with J-B Bore Cleaner 10+ times before first shot (This lapping process will smooth the barrel and reduce future cleaning), reduce to 5 times after first shot. Repeat if necessary.

Clean breech from bore cleaner with toothbrush and Prolix to prevent next step from bringing excess bore cleaner at breech into barrel.

Run 1 patch soaked with Prolix both sides. Repeat if necessary.

Run a plain felt button smeared with J-B Bore Bright 10+ times before first shot (This polishing will reduce future cleaning), reduce to 5 times after first shot. Repeat if necessary.

Clean breech from bore bright with toothbrush and Prolix to prevent next step from bringing excess bore bright at breech into barrel.

Run 1 patch soaked with Prolix, both sides. Repeat if necessary.

First time and last time only: Soak all gun parts with Prolix for 20 minutes. Drip dry, assemble and lubricate with one drop of Xtra-T Lube, each place in manual.

Before shooting (not before storage) run 3 dry patches, both sides.

Shoot 1, 2, 4, 8, 16, 32, and 64 rounds, each followed by above process except second last step, soaking.

To complete at the end, after the final soaking and lubricating, (Prolix snap cap for rim fires) touch up wipe outside of gun with Prolix on a cloth, and store in silicone sock.

## NORMAL CLEANING PROCESS (After break in)

Before range/shooting: run Patchworm with dry patch, each both sides. Repeat until patch is clean.

Bring to range: Patchworm, 4 patches soaked with Prolix, toothbrush and very small container of Prolix.

Immediately after range while gun is still warm: run Patchworm with patch soaked with Prolix, both sides. Repeat until patch is clean (2-4 times)

Clean breech down to magazine, trigger linkage, and top of trigger with toothbrush and Prolix.

## ANNUALLY AND FOR LONG TERM STORAGE

Run Patchworm with 1 patch soaked with Prolix, both sides.

Run a super intensive felt button dipped in Prolix and smeared with J-B Bore Cleaner 5 times.

Clean breech from bore cleaner with toothbrush and Prolix.

Run a patch soaked with Prolix both sides. Repeat if necessary.

Run a plain felt button dipped in Prolix and smeared with J-B Bore Bright 5 times.

Clean breech from Bore Bright with toothbrush and Prolix.

Run a patch soaked with Prolix, both sides. Repeat if necessary.

Soak all gun parts with Prolix for 20 minutes. Assemble and lubricate with one drop of Xtra-T Lube, each place in manual. Prolix snap cap for rim fires, touch up wipe outside of gun with Prolix on a cloth, and store in silicone sock.

### Xtra-T Lube:

22A: 4 points on slide

Remington 870: None mentioned

Ruger 10/22: None mentioned

Ruger Mini 14: None mentioned

Glock: Slides, left top of slide, trigger to connector at right rear

KelTec SU16: None mentioned